



ENVIRONMENTAL WATER SYSTEMS®
Quality Water Filtration Crafted in the USA Since 1987.

ORDERING FILTER REPLACEMENT AND PARTS

Item #: **BB-081**
Replacement filter for
BB 1" SETUP
used with 3/4 to 1" water lines
and
BB 1-1/2" SETUP
used with 1-1/4 to 1-1/2" water lines



There are a few ways to order filter replacements for your unit.

1. Contact your contractor and/or your installer that provided the product.
2. Contact the showroom or retailer where you purchased the product.
3. Contact an EWS authorized online distributor

Do not accept non-EWS filters
or knock-off or look-a-like product.

If you need assistance, visit our Corporate Site @ www.ewswater.com
or contact EWS Customer Service and we can direct you to someone
who may assist you.



**ALL FILTRATION PRODUCT PROUDLY
MADE & ASSEMBLED IN THE USA**

www.ewswater.com O: 702.256.8182; M-F 8:00am-4:30pm PST
E: customerservice@ewswater.com

Revised 9/17

FILTER REPLACEMENT

For
BB SETUP
5 Micron Pre-Sediment Filter



BB-081
filter replacement for the
BB 1" SETUP
BB 1-1/2" SETUP



ENVIRONMENTAL WATER SYSTEMS®
Quality Water Filtration Crafted in the USA Since 1987.

WWW.EWSWATER.COM

Customer Service Monday–Friday 8:00am–4:30pm PST
Office: 702-256-8182 Fax: 702-256-3744
customerservice@ewswater.com

EWS, Inc. Corporate Offices
5542 S. Ft. Apache Rd, Suite 110
Las Vegas, NV 89148

REPLACING THE FILTER

1. Turn off water supply to filter.
2. Depress the RED pressure release button to relieve pressure in filter housing.
3. Unscrew blue housing using spanner wrench.

CAUTION:

Do not lose O-Ring that is in blue housing. When opening housing to change cartridge, it is common for the O-Ring to lift out of blue housing or stick to black cap.

4. Remove used cartridge and discard. Rinse out blue housing and fill about 1/3 full with water.


Suggestion: Add about 2 to 3 tablespoons of bleach and scrub thoroughly with a brush or sponge. Rinse thoroughly.

5. Remove O-Ring from blue housing and wipe groove and O-Ring clean. Lubricate O-Ring with a coating of clean silicone grease. (Do not use Vaseline or other petroleum-based lubricants.)

Place O-Ring back in place and press O-Ring down into the groove with two fingers. Make sure the O-Ring is seated level in the groove.

CAUTION:

If O-Ring appears damaged or crimped it should be replaced at this time. See your local dealer for replacement parts.



**CORRECT
INSTALLATION:
WITH A PLUMBER
INSTALLED BYPASS**

REPLACING THE FILTER - continued

6. Insert the new pre-sediment replacement filter cartridge into the blue housing making sure that it slides down over the stem found at the bottom of the housing.

CAUTION:

The filter must be properly inserted over the stem located at the bottom of the housing before you go to Step # 7.

WARNING:

Misplacement of the filter can cause damage to the housing.

7. Place the top of the filter under the stem found in the base of the black cap, make sure the O-Ring is in the correct position and twist the blue housing onto the black cap and hand tighten. DO NOT OVER-TIGHTEN.

CAUTION:

Make sure the top of the filter is properly inserted over the stem found at the base of the black cap before completely hand tightening.

WARNING:

Misplacement of the filter can cause damage to the housing.

8. Turn on the water supply slowly to allow housing to fill with water.
9. Depress the RED pressure release button to release trapped air from the unit
10. Check the installation for any leaks.

**FILTER SERVICE LIFE IS BASED ON LOCAL WATER CONDITIONS
AND USAGE AND SHOULD BE REPLACED AS NEEDED,
NOT TO EXCEED ONE YEAR.**